

STEP

1



FloraFlex®

Helping you grow with your garden.®


SEEDLING GERMINATION W/ FLORAFOAM INCUBATOR PLUGS 40|40

Light Cycle 18-24 Hours (80 - 160 umol)

Germination	 75° - 80° F	 75° - 80° F	Sprouted
	 75% - 80% Inside The Dome	 65% - 70% Inside The Dome	

PROCESS

- Place the FloraFoam Incubator Plugs 40|40 in the Incubator 50 Cell Inner Tray.
- Pre-Soak the FloraFoam Incubator Plugs 40|40 by pouring your B1:B2:Root Drip Nutrient solution across the top of the FloraFoam Incubator Plugs allowing excess water to fill up the Incubator bottom tray. Allow them to soak for 10 minutes. Drain excess water from the bottom tray leaving just enough water to reach the top of the bottom grooves in the Incubator Bottom Tray.
- Force seeds 1/2 way into the plug (e.g. toothpick). All seeds should sprout within 2-7 days.
- After seeds sprout, open top vents of dome and slide it to the side to allow airflow through our patented convection design.
- Remove the dome completely once seedlings have 2-3 sets of fan leaves.
- Begin watering with 1g of each B1:B2 & 1 mL Root Drip per gallon and leave 200-400 ml in the bottom tray.
- Transplant into no larger than a 1 gal pot/cube. Next see Step 3 (Early Veg).



Day 0

Day 10-14